


PART LIST AND DIAGRAM
Double diaphragm pump BOXER 5



PART LIST AND DIAGRAM
Double diaphragm pump BOXER 5

Ref.	Description	Q.ty
12001	Double diaphragm pump BOXER 5	
002109	SCHNOOR WASHER	12
010124	BALL SEAT GASKET	1
012012	BALL dia.11, NYLON	4
012103	DIAPHRAGM, BOXER	2
012105	SHAFT GUIDE BOXER	2
012106	O.R. RING	2
012107	SEAL RING	2
012108	SHAFT BOXER	1
012111	O.R. RING IN TEFLON, SUCTION VALVE	2
012112	SUCTION VALVE BODY	2
012113	RAPID ADAPTOR M1/8" dia.4-6	1
012114	COMPRESSION VALVE PLUG	2
012115	DUMP VALVE FF 1/4"	1
012116	COPPER GASKET	1
012117	PLUG	1
012119	NIPPLE M1/4" - M3/8"	1
012124	RAPID ADAPTOR M1/4" dia.4-6	2
012126	FIXING SCREW	1
012127	"NOT" UNIT	2
012128	VALVE ISO 1	1
012129	RILSAN HOSE dia.4x6 - cm.30	1
012132	SEEGER	2
012352	RAPID ADAPTOR M1/4" dia.6-8	1
012501	PLASTIC HEAD, RIGHT	1
012502	PLASTIC HEAD, LEFT	1

Ref.	Description	Q.ty
012510	BALL SEAT	2
012515	FIXING BOLT	10
012550	PUMP HOUSING	1
012551	HEAD CONNECTING	2
012552	O-RING, VITON	4
012700	HANDLE	1
012701	PLATE	1
012705	NUT 3/8"	1
012710	REDUCERS SET 3/8"	1
012805	KIT LINE FILTER COMPLETE	1
013129	COPPER GASKET 1/2"	1
016652	SELF LOCKING NUT M8	2
064011	NIPPLE M1/4" - M1/2"	1
064041	FITTING M3/8" - F1/4"	1
3214NY	PLUG	4