


PART LIST AND DIAGRAM
Electric Diaphragm Airless Pump GOLD 6500



PART LIST AND DIAGRAM
Electric Diaphragm Airless Pump GOLD 6500

Ref.	Description	Q.ty
6500	Electric Diaphragm Airless pump GOLD 6500 - S.S.	
002109	SCHNOOR WASHER	1
003221	SCRAPER RING	1
003224	COPPER GASKET	6
005106	HEAD BOLT	1
005201	CAM'S SHAFT, COMPLETE	1
005202	FIXING RING NUT	1
005203	WASHER	1
005206	LOWER BEARING	4
005217	FIXING BOLT, MOTOR	4
005218	FIXING NUT, MOTOR	4
005219	WASHER	1
005220	FLYWHEEL JOINT	1
005221	RING NUT	1
005222	OIL SEAL	1
005223	FLANGE	1
005224	FLANGE COVER	1
005225	O.R.	1
005226	MOTOR JOINT	1
005227	CLUTCH INSERT	6
005228	FLANGE SCREW	6
005229	FIXING BOLT	1
005230	UPPER BEARING	6
005233	WASHER SCHNOOR	1
005237	SHAFT KEY	1
005254	O.R. GASKET	1
006511	HEAD BLOCK, S.S.	1
006512	PISTON SLEEVE	1
006513	PISTON	1
006514	SLEEVE O-RING	1
006515	SLEEVE O-RING	1
006516	PISTON SPRING	1
006520	CONDENSER 31,5 MF	1
006521	MOTOR PROTECTOR 12 A.	1
006523	OIL FILTER	1
006704	HYDRAULIC BODY	1
006901	ELECTRIC MOTOR HP 2 - 220 Volt/50 Hz	1
008208	SLEEVE PIN	1
008209	WASHER	1
008211	FIXING RING NUT	1
010103***	DIAPHRAGM, COMPLETE	1
010104***	DIAPHRAGM SUPPORT	6
010106	WASHER SCHNOOR	1
010116**	SUCTION VALVE GASKET	1
010121***	BALL SPRING	1
010122***	SUPPORT RING, TEFLON	1
010128*	DUMP VALVE, S.S.	1
010129*	COPPER SEAL	1
010148**	SUCTION VALVE	1
010216	PRESSURE REGULATING VALVE	1
010217	KNOB, REGULATING VALVE	1
010220	OIL LEVEL GLASS	1
010221	PLUG VENT	1
010309	FLYWHEEL JOINT KEY	1
010406	SWITCH COMPLETE 220 Volt	1
010410	CONDENSER BOX	1
010619***	BALL SEAT CPL.	1
010621***	COMPRESSION VALVE PLUG	1

Ref.	Description	Q.ty
010623***	COPPER GASKET	1
010627***	BALL SEAT GASKET	1
010870	FIXING SCREW	1
022120***	BALL dia.14, T.C.	1
064010	NIPPLE S.S. MM16x1,5	1
077114	COPPER GASKET	1
005800	UNIVERSAL TROLLEY KIT:	1
001037	SPLIT PIN, UNIVERSAL TROLLEY	2
002109	SCHNOOR WASHER	4
005107	PLUG dia.30	2
005703	HANDLE, UNIVERSAL TROLLEY	1
005704	BODY, UNIVERSAL TROLLEY	1
005705	FIXING BOLT	4
005706	PLATE, UNIVERSAL TROLLEY	1
010703	WHEEL	2
010704	COTTER PIN	2
010707	TOOL BOX "TAIVER"	1
010708	SUCTION SYSTEM HOLDER	1
010710	FIXING BOLT	2
010711	WASHER	2
010712	FIXING NUT	2
020806	BOLT	4
020854	BOLT	4

Spare parts suggested:		
10328	DUMP VALVE KIT,S.S. (*)	
10348	SUCTION VALVE KIT (**)	
10618	COMPRESSION VALVE KIT (***)	
10803	DIAPHRAGM/SUPPORT KIT (****)	