


PART LIST AND DIAGRAM
Screw pump MTV 80



PART LIST AND DIAGRAM

Screw pump MTV 80

Ref.	Description	Q.ty
17000	Screw pump MTV 80	
001037	SPLIT PIN, UNIVERSAL TROLLEY	2
005218	FIXING NUT	2
005703	HANDLE, UNIVERSAL TROLLEY	1
005704	BODY, UNIVERSAL TROLLEY	1
009215	FIXING SCREW	4
010703	WHEEL	2
010704	COTTER PIN	2
010707	TOOL BOX "TAIVER"	1
010708	SUCTION SYSTEM HOLDER	1
010710	FIXING BOLT	2
010711	WASHER	2
017102	BAR	1
017103	ELECTRONIC BOARD MTV 80	1
017105	TANK 40 lts IN S.S.	1
017106	FILTERING RETICLE FOR TANK MTV	1
017107	BASE FOR TANK SUPPORT	1
017111	TIE-ROD	4
017112	ADJUSTING STATOR	1
017113	FLANGE, STATOR MTV	1
017114	STATOR MTV 80	1
017115	ROTOR MTV 80	1

Ref.	Description	Q.ty
017116	MIXING BLADE MTV	1
017117	JOINT	1
017118	FLANGE MTV	1
017119	REDUCER MTV	1
017128	PROTECTION IN RUBBER	1
017129	SCREW	1
017131	BOLT	4
017132	BOLT	2
017134	O-RING	1
017138	SEAL GASKET	1
020806	BOLT	4
020853	OUTLET VALVE FF 1"	1
020854	BOLT	4