






PART LIST and DIAGRAM

**Pneumatic Airless Pump IP 281 ABRASPRAY - (30:1) - pneumatic part**



## PART LIST and DIAGRAM

**Pneumatic Airless Pump IP 281 ABRASPRAY - (30:1) - pneumatic part**

Ref.	Description	Q.ty	Ref.	Description	Q.ty
<b>22000</b>	<b><i>Pneumatic airless pump ABRASPRAY</i></b>				
000159	CAP	1	023124	AIR CLUTCH FLANGE	1
000928	WASHER, SUCTION VALVE	1	023127	SOCKET SCREW	4
003222	O.R.	1	023129	GASKET	2
004201	OIL LEVEL GLASS	1	023130	AIR CYLINDER	1
005229	FIXING BOLT	4	023131	PISTON FIXING NUT	1
005233	WASHER SCHNOOR	1	023133	AIR MOTOR PISTON	1
007107	GASKET	1	023134	LUBRORING	2
010105	BOLT	4	023135	AIR CONNECTION TUBE	2
010106	WASHER SCHNOOR	4	023136	ROD	1
010121	SPRING	1	023137	SHAFT, MOTOR PISTON	1
010711	WASHER	4	023138	SEEGER	1
012355	NIPPLE MM3/8"	1	023140	LOWER FLANGE BUSH	1
021760	FIXING SCREW	2	023177	SPRING FOR REVERSAL KIT	2
022119	COPPER GASKET 3/8"	2	023178	REVERSAL KIT PISTON	2
023015	COVER, MOTOR SILENCER	1	023179	REVERSAL CONTROL SYSTEM	1
023016	FILTER NET	1	023200	RING	1
023017	SILENCER	1	023541	LOWER FLANGE	1
023018	AIR CONTROL VALVE BODY	1	024107	SELF-LUBRICATING BUSH	1
023019	UPPER FLANGE	1	024109	SPRING	1
023101	COVER COMPLETE WITH BUSH	1	024110	UPPER GUIDE	2
023102	GASKET	1	024113	LOWER BUFFER	1
023103	UPPER BUFFER	1	024127	BOLT	1
023104	PILOT SHAFT	1	024130	SPRING GUIDE	1
023105	AIR CONTROL VALVE SUPPORT	1	024153	LUBRORING	1
023108	WASHER	1	024200	PRES. REDUCER 3/8" CPL. WITH GAUGE	1
023113	PISTON BODY	2	067127	CONICAL PLUG 1/4"	5
023114	GASKET	3			
023116	GASKET	8			
023117	GASKET	1			
023118	GASKET	1			