



PART LIST AND DIAGRAM
Pumping part HTP 21000



PART LIST AND DIAGRAM
Hydraulic part & Trolley



PART LIST AND DIAGRAM HTP 21000 GAS ENGINE

Ref.	Description	Q.ty	Ref.	Description	Q.ty
21670	Hydraulic pump HTP 21000 GAS ENGINE				
21800	Pumping part HTP 21000				
00925H***	SEAT	1	021856	PIN	1
002122**	SEAT	1	021857	MATERIAL PISTON	1
003224	COPPER GASKET	3	021858	CUP SPRING	1
005218	FIXING NUT	2	021859	SPRING	1
005219	FIXING WASHER	2	021860**	COMPRESSION VALVE BODY	1
012011**	BALL dia.11, S.S.	2	021861	SPACER, PAINT PART	1
012116	COPPER GASKET	2	021862	CONNECTING NIPPLE	1
016126***	BALL dia.25 IN S.S.	1	021863	PRODUCT CYLINDER	1
021801	RESET NUT	1	021864	BALL STOP COMPLETE	1
021802	RELEASE BODY	1	021865	PLUG 1/2" S.S.	1
021803	O-RING	1	022119	COPPER GASKET	1
021804	RESET PIN	1	023161	BALL STOP RING	1
021805	MOBILE FUSE	1	023162	NON-BACKFLOW VALVE NIPPLE	1
021806	BALL, TRACER POINT	2	064086	NIPPLE M3/8" - M16x1,5 - S.S.	2
021807	TRACER POINT	2	079011	SELF-LOCKING NUT	2
021809	PLUG	1			
021810	SPRING, TRACER POINT	2	Ref.	Description	Q.ty
021811	BALL STOP RING	1		Hydraulic part & Trolley	
021812	PISTON SLEEVE, FUSE	1	002702	FIXING SCREW	4
021813	SEEGER S.S.	1	005218	FIXING NUT	4
021814	FIXING RING NUT	1	005219	FIXING WASHER	4
021815	O-RING	2	005715	FIXING BOLT, TROLLEY	4
021816	OLEODYNAMIC CYLINDER	1	005716	BOLT	2
021818	PUMPING HOUSING DOUBLE	1	005717	NUT	2
021819	VALVE ROD	1	005774	COTTER PIN	2
021820	WASHER	2	005850	KIT TROLLEY HTP 21000 GAS ENGINE	1
021821	SPRING GUIDE	1	010707	TOOL BOX "TAIVER"	1
021822	SPRING	1	010710	FIXING BOLT	2
021825	NUT	1	010711	WASHER	2
021826	SCRAPER PISTON	1	010712	FIXING NUT	2
021827	OLEODYNAMIC SHAFT	1	012116	COPPER GASKET	2
021828	STOP RING	1	016134	FIXING WASHER	4
021829	SPRING	1	016301	RUBBER FOOT	2
021830	O-RING	1	020760	WHEEL, BIG	2
021833	REVERSAL BODY	1	020806	BOLT	2
021834	NIPPLE	1	021610	ADAPTOR PUMP HTP 21000 GAS ENGINE	1
021835	OR SEAL	3	021611	RADIATOR	1
021836	WASHER	1	021640	GAS ENGINE, HTP	1
021837	OIL HOSE	1	021699	HYDRAULIC BOX, HTP 21000 GAS ENGINE	1
021838	"T" FITTING 3/8"	1	021751	PULLEY WITH BUSH	1
021839	NIPPLE 3/8 FF	1	021753	BELT	1
021840	VALVE 3/8 FF	1	021755	PULLEY SMALL WITH BUSH	1
021841	SAFETY SPRING	1	021883	CONNECTING HOSE cm. 60	2
021844	PLUNGER SCRAPER	1	023810	KIT LINE FILTER WITH DUMP VALVE S.S. AND	1
021845	O-RING	1	064086	NIPPLE M3/8" - M16x1,5 - S.S.	2
021846	PUMPING HOUSING CENTRAL	1			
021847***	O-RING	2	Spare parts suggested:		
021848*	UPPER & LOWER PACKING	2	021603	UPPER AND LOWER PACKINGS SET (* x2)	
021849	EXTENSION	1	021618	COMPRESSION VALVE KIT (**)	
021850	STATIC SCRAPER	1	021648	SUCTION VALVE KIT (***)	
021851	DUST COVER	1			
021852***	SUCTION BODY	1			
021853	FILTERING DISC	1			
021854	FIXING SCREW	2			
021855	SPRING, UPPER PACKING	1			