


PART LIST AND DIAGRAM

T88 gun



Ref.	Description
88913	Nozzle-cap-needle kit.....dia. 1,3
88915	Nozzle-cap-needle kit.....dia. 1,5 (standard)
88918	Nozzle-cap-needle kit.....dia. 1,8

Ref.	Description	Q.ty
88700	T 88 gun, pressure	
88800	T 88 gun, with lower cup	
088003	SCREW KIT	1
088004	T-88 GUN BODY	1
088005	REGULATING FAN KIT	1
088006	PLUG	1
088007	GUIDE BODY	1
088009	MATERIAL ROD SPRING	1
088010	FIXING RING NUT	1
088011	FLUID ADJUSTING KNOB	1
088012	AIR VALVE SEAT KIT FOR	1
088013	AIR VALVE	1
088014	SPRING	1
088015	AIR VALVE SPRING SEAT	1
088016	AIR HOSE JOINT	1

Ref.	Description	Q.ty
088017	AIR ADJUSTING VALVE KIT	1
088018	TRIGGER PIN	1
088020	TRIGGER LOCK	1
088021	FLUID INLET NIPPLE	1
088313	SPRAY TIP dia. 1,3	1
088513	AIR CAP dia.1,3	1
088813	NEEDLE dia. 1,3	1
For Cup version:		
101002	LOWER CUP Itr.1 COMPLETE	1